
Mini Arm v4.0

Installation Instructions


1. START




Remove the part from the board.



Remove the protective film.





2. Start with simple parts




1 Servo, 2 Long set screw, Claw parts

Be sure to insert the acrylic parts vertically, and do not shake them from side to side, otherwise they may crack.







The mounting position of the claw has a range of motion between 0° and 180° degrees.




The claws are all installed.

3. Officially begin




Install the Right Arm Servo.



Installation position of swing arm.



Install the Left Arm Servo. Same as the right arm.



The range of motion of the big arm.




The other side of the big arm - Joint Screw. Tighten first, then back 1/4 turn to allow the two parts to rotate freely.





4. Assemble the body








Lightly tighten the 2 screws under the base.


















5.Install Upper Arm and Connecting Rod









Do not tighten the joint screws, so that the parts can rotate freely.





